


FILTRATION FAUCET VALVE CARTRIDGE REPLACEMENT

BEFORE YOU BEGIN YOUR INSTALLATION:



Turn off water supply.

REQUIRED TOOLS:



Adjustable Wrench



1/8 Hex Key Wrench



Pliers



3/8" 6-Point Socket Wrench



41180 Raintree Court, Murrieta, CA 92562

1-888-304-0660 • 951-304-0520

www.waterstoneco.com

038-FFRV Rev. C

TRADITIONAL HOT OR COLD ONLY MODEL #S I100, I150, I200, I250, I700, I750

- Place a sandwich bag over cover screw (A) to avoid scratching finish. Unscrew with socket wrench (B) and remove.
- Remove handle (C) from valve (D). Wiggle handle back and forth to help remove.
- Unscrew valve cartridge and remove. Insert new cartridge (E) into valve body (F). Tighten until snug. Slide handle back over valve spline. Check alignment of handle. It should be in the closed position and vertical. Replace valve cover screw and hand tighten. Place sandwich bag back over cover screw and tighten with socket driver. **DON'T** use pliers to tighten screw.

NOTE - FOR COLD ONLY FAUCETS, REMOVE ADAPTER SLEEVE

CONTEMPORARY HOT OR COLD ONLY MODEL #S I400, I425, I900

- Wrap handle (A) with a cloth to protect finish, loosen with pliers and remove. Using a 1/8 hex key wrench, loosen set screw (B) 1 or 2 turns.
- Remove valve cover (C) from valve (D) by pulling straight out. Wiggle cover back and forth to help remove.
- Unscrew cartridge and remove. Insert new cartridge (E) into valve body (F) and tighten until snug. Slide valve cover back over valve spline. Check alignment of handle. It should be in the closed position and vertical. Tighten set screw securely and connect handle.

NOTE - FOR COLD ONLY FAUCETS, REMOVE ADAPTER SLEEVE

TRADITIONAL HOT AND COLD ONLY MODEL #S I100HC, I150HC, I200HC, I250HC, I700HC, I750HC

Place a sandwich bag over cover screws (A) to avoid scratching finish. Unscrew with socket wrench and remove. Remove handles (B) from valves (C). Wiggle handles back and forth to help remove. Unscrew valve cartridges and remove. The adapter sleeve may or may not come out. Replace sleeves if needed. Insert new cartridges into valve bodies (D). Tighten until snug. Slide handles back over valve splines. Handle position should be in the closed position and vertical. Replace valve cover screws and hand tighten. Place sandwich bag back over cover screws and tighten. **DON'T** use pliers.

NOTE - REPLACE OLD ADAPTER SLEEVE IF NEEDED.

CONTEMPORARY HOT AND COLD ONLY MODEL #S I400-HC, I425-HC, I900-HC

Wrap handles (A) with a cloth to protect finish, loosen with pliers and remove. Using a 1/8 hex key wrench, loosen set screws (B) 1 or 2 turns. Remove valve covers (C) from valves (D) by pulling straight out. Wiggle cover back and forth to help remove. Unscrew cartridges on both sides and remove.

The adapter sleeve may or may not come out. Replace sleeves if needed. Insert new cartridges into valve bodies (E) and tighten until snug. Slide valve covers back over valve splines. Handle position should be in the closed position and vertical. Tighten set screws securely and connect handles.

NOTE - REPLACE OLD ADAPTER SLEEVE IF NEEDED.